




# Viking™ Assembly Guide



Please check whether there is any component missing before assembly.




## STEP 1 A + B



Place the parts on the carton or a table for easier assembling.


Install the screws to the seat back with the included G hex wrench.



⚠ Make sure all the F screws are installed in correct places, and then tightened every screws with the hex wrench.

## STEP 2 B + C


Insert the C gas lift directly to the B tilt mechanism.



⚠ Beware of the lubricant when holding the C gas lift.

## STEP 3 D + E



Install the E casters to the D seat base, and place the seat base on the assembled A seat back, B seat, and C gas lift.



⚠ Push the E casters hard until you hear a clear "click".

### Seat Back Adjustment



Pull the seat back up to the preferred height.



### Lumbar Support Adjustment

#### a. Height Adjustment

Push the lumbar support to the preferred height



#### b. Tension Level Adjustment



Push the control knob upward to tighten the lumbar support, Pull the control knob downward to loose the lumbar support.



### Armrest Adjustment


#### a. Height Adjustment

Press the button below the armrest pad to adjust the height.




#### b. Rotation Adjustment

Press the button on the armrest elbow to rotate the armrest backward.




### Tilt Mechanism and Seat Back Adjustment



#### Slide the seat with lever (b)

1. Sit on the chair and lift lever (b) up to slide the seat forward.

2. Slightly stand up and lift lever (b) again to slide the seat back to normal position.




#### Adjust the seat height and recline with lever (a)

1. Press the lever (a) forward to adjust seat height.

2. Pull the lever (a) out from the tilt mechanism to recline.

3. Push the lever (a) into the tilt mechanism to lock in certain position.



#### Adjust the tension of the seat back reclination with knob (c)

1. Rotate clockwise to reduce the tension.

2. Rotate counter-clockwise to raise the tension.

